

# Alesis FireWire Mac Driver and Software

June 2010

## A. FIRST STEP: READ THIS DOCUMENT

*Driver 3.5.3.8671 includes support for Mac OS 10.6 "Snow Leopard" (32-bit and 64-bit kernel).*

***FOR TROUBLE-FREE RESULTS, DO NOT CONNECT YOUR ALESIS FIREWIRE DEVICE TO YOUR COMPUTER UNTIL INSTRUCTED TO DO SO.***

## B. SECOND STEP: INSTALL THE MAC DRIVER AND HARDWARE DIRECT MONITORING APPLICATION

1. Double click *AlesisFirewire.dmg*. Then, open the drive that appears on your desktop.
2. Run the *AlesisFirewireUninstaller* program to remove any prior Alesis Firewire audio drivers on your system. *(You can skip this step if you have never installed an Alesis Firewire device on your computer.)*
3. Run *AlesisFirewire-3.5.3.8671.pkg* to install the current driver.
4. (IO|14 or IO|26 only) Run *AlesisHDM\_1\_29\_1.pkg* from *AlesisHDM1\_29\_1.pkg.zip* to install the Hardware Direct Monitoring application. Any prior installation will be automatically overwritten.

***Your new software and drivers are now installed and ready for use. Attach your Alesis Firewire device to your computer now.***

## C. IN CASE OF DIFFICULTY

Alesis's customer support team is available for further troubleshooting and consultation. Call (401) 658-5760 ext. 1409.

Thank you for using Alesis products. Best of luck to you in all your creative endeavors!

*The Alesis Team*