

Vortex Wireless 2

Latest Firmware Version: 1.1.5

Release Date: July 11, 2018

Minimum System Requirements

- Windows 7 (32- or 64-bit) or macOS 10.10
- Host USB 2.0 port

Firmware Update Instructions

1. Open the **Install Alesis Vortex Wireless 2 Firmware Updater 1.1.5** application for your operating system—Windows or macOS. (You may need to unzip an additional .zip file to access the actual application.)

You may see a Windows prompt asking if you trust this application to make changes to your device. Select **Yes** or **OK**. Wait for C++ to update (this may take several minutes).

2. Once the installation is complete, open the **Vortex Wireless 2 Firmware Updater** application.
3. Connect your Vortex Wireless 2 to your computer's USB port, and ensure Vortex Wireless 2 and your computer are powered on.
4. When the updater window appears, click **Update Firmware**.
5. Power your Vortex Wireless 2 off. While holding the lowest **C** and **Eb** keys, power it on again (**UUU** will appear in its display). Click **Next** in the software window.

Do **not** disconnect or power off Vortex Wireless 2 or your computer until the update is completed.

6. When the update is completed, the updater will prompt you to power your Vortex Wireless 2 off and then on again. Click **Next** and then click **Exit** to close the updater window.

Congratulations—your Vortex Wireless 2 now has the latest firmware!

For additional help, visit alesis.com/support.

Change History

Changes Since 1.1.4

- Minor bug fixes.