

Command Mesh Kit - Kit & Voice List

Kits

#	Kit
1	Acoustic 1
2	Funk
3	Standard 1
4	Rock
5	Power
6	Jazz
7	808
8	Pop
9	1970s
10	Latin
11	FX Mix
12	Percussion 1
13	Percussion 2
14	Indian
15	African
16	World
17	Orchestra

#	Kit
18	Marimba
19	Vibraphone
20	HipHop
21	909
22	Dance
23	Electronic
24	Drum & Bass
25	House
26	Techno
27	Noise
28	Junkyard
29	Lo-Fi
30	Reggae
31	Ska
32	Songo
33	Fusion
34	Jazz Latin

#	Kit
35	Jazz Brush
36	Big Band
37	Brush
38	Magic
39	FunkBand
40	Old School
41	R&B
42	Studio 1
43	Studio 2
44	Standard 2
45	Vintage
46	Acoustic 2
47	Live
48	Room
49	Metal
50	90s Power

Voices

Voice

1	22" Acoustic Kick 1
2	22" Acoustic Kick 2
3	24" Standard Kick
4	Brush Kick 1
5	Brush Kick 2
6	24" Jazz Kick
7	22" Rock Kick
8	Room Kick
9	Fusion Kick
10	1970's Kick
11	Vintage Kick
12	HipHop Kick
13	Reggae Kick
14	Big Band Kick
15	Old School Kick
16	Lo-Fi Kick
17	Junkyard Kick
18	Noise Kick
19	Drum & Bass Kick
20	808 Kick
21	909 Kick
22	Electronic Kick
23	Power Kick
24	Dance Kick
25	FX Mix Kick
26	Techno Kick
27	Magic Kick
28	14" Acoustic Snare
29	14" Acoustic Snare Rim
30	14" Standard Snare
31	14" Standard Snare Rim
32	14" Funk Snare 1
33	14" Funk Snare Rim 1
34	14" Funk Snare 2
35	14" Funk Snare Rim 2
36	Brush Snare 1
37	Brush Snare Rim 1
38	Brush Snare 2
39	Brush Snare Rim 2
40	14" Jazz Snare
41	14" Jazz Snare Rim
42	14" Rock Snare
43	14" Rock Snare Rim

Voice

44	13" Damped Snare 1
45	13" Damped Snare 2
46	13" Damped Snare 3
47	Orchestra Snare
48	Orchestra Snare Rim
49	Room Snare
50	Room Snare Rim
51	Fusion Snare
52	Fusion Snare Rim
53	Big Band Snare
54	Big Band Snare Rim
55	Vintage Snare
56	Vintage Snare Rim
57	Live Snare
58	Live Snare Rim
59	Reggae Snare
60	Reggae Snare Rim
61	R&B Snare
62	R&B Snare Rim
63	808 Snare
64	808 Snare Rim
65	909 Snare
66	909 Snare Rim
67	Electronic Snare
68	Power Snare
69	Dance Snare
70	Dance Snare Rim
71	Old School Snare
72	Old School Snare Rim
73	House Snare
74	House Snare Rim
75	Lo-Fi Snare
76	Lo-Fi Snare Rim
77	Junkyard Snare
78	Junkyard Snare Rim
79	Noise Snare
80	Noise Snare Rim
81	Drum & Bass Snare
82	Drum & Bass Snare Rim
83	Techno Snare
84	Techno Snare Rim
85	Magic Snare
86	Magic Snare Rim

Voice

87	Acoustic Snare Stick
88	Standard Snare Stick 1
89	Brush Snare Stick
90	Standard Snare Stick 2
91	Rock Snare Stick 1
92	Rock Snare Stick 2
93	Live Snare Stick
94	Room Snare Stick
95	Fusion Snare Stick
96	808 Snare Stick
97	909 Snare Stick
98	Electronic Snare Stick
99	Old School Snare Stick
100	House Snare Stick
101	Lo-Fi Snare Stick
102	Junkyard Snare Stick
103	Noise Snare Stick
104	Techno Snare Stick
105	Brush Swirl
106	Acoustic Tom 1
107	Acoustic Tom 1 Rim
108	Acoustic Tom 2
109	Acoustic Tom 2 Rim
110	Acoustic Tom 3
111	Acoustic Tom 3 Rim
112	Acoustic Tom 4
113	Acoustic Tom 4 Rim
114	Acoustic Tom 5
115	Acoustic Tom 5 Rim
116	Acoustic Tom 6
117	Acoustic Tom 6 Rim
118	Standard Tom 1
119	Standard Tom 1 Rim
120	Standard Tom 2
121	Standard Tom 2 Rim
122	Standard Tom 3
123	Standard Tom 3 Rim
124	Standard Tom 4
125	Standard Tom 4 Rim
126	Standard Tom 5
127	Standard Tom 5 Rim
128	Standard Tom 6
129	Standard Tom 6 Rim

#	Voice
130	Brush Tom 1
131	Brush Tom 1 Rim
132	Brush Tom 2
133	Brush Tom 2 Rim
134	Brush Tom 3
135	Brush Tom 3 Rim
136	Brush Tom 4
137	Brush Tom 4 Rim
138	Brush Tom 5
139	Brush Tom 5 Rim
140	Brush Tom 6
141	Brush Tom 6 Rim
142	Funk Tom 1
143	Funk Tom 1 Rim
144	Funk Tom 2
145	Funk Tom 2 Rim
146	Funk Tom 3
147	Funk Tom 3 Rim
148	Funk Tom 4
149	Funk Tom 4 R
150	Funk Tom 5
151	Funk Tom 5 Rim
152	Funk Tom 6
153	Funk Tom 6 Rim
154	Jazz Tom 1
155	Jazz Tom 1 Rim
156	Jazz Tom 2
157	Jazz Tom 2 Rim
158	Jazz Tom 3
159	Jazz Tom 3 Rim
160	Jazz Tom 4
161	Jazz Tom 4 Rim
162	Jazz Tom 5
163	Jazz Tom 5 Rim
164	Jazz Tom 6
165	Jazz Tom 6 Rim
166	Rock Tom 1
167	Rock Tom 1 Rim
168	Rock Tom 2
169	Rock Tom 2 Rim
170	Rock Tom 3
171	Rock Tom 3 Rim
172	Rock Tom 4
173	Rock Tom 4 Rim
174	Rock Tom 5

#	Voice
175	Rock Tom 5 Rim
176	Rock Tom 6
177	Rock Tom 6 Rim
178	Fusion Tom 1
179	Fusion Tom 2
180	Fusion Tom 3
181	Fusion Tom 4
182	1970's Tom 1
183	1970's Tom 2
184	1970's Tom 3
185	1970's Tom 4
186	Vintage Tom 1
187	Vintage Tom 2
188	Vintage Tom 3
189	Vintage Tom 4
190	Vintage Tom 5
191	Vintage Tom 6
192	808 Tom 1
193	808 Tom 2
194	808 Tom 3
195	808 Tom 4
196	808 Tom 5
197	808 Tom 6
198	808 Tom Fx 1
199	808 Tom Fx 2
200	909 Tom 1
201	909 Tom 2
202	909 Tom 3
203	909 Tom 4
204	909 Tom 5
205	909 Tom 6
206	909 Tom 7
207	909 Tom 8
208	Electronic Tom 1
209	Electronic Tom 2
210	Electronic Tom 3
211	Electronic Tom 4
212	Electronic Tom 5
213	Electronic Tom 6
214	Electronic Tom 7
215	Electronic Tom 8
216	Power Tom 1
217	Power Tom 2
218	Power Tom 3
219	Power Tom 4

#	Voice
220	Power Tom 5
221	Power Tom 6
222	90's Power Tom 1
223	90's Power Tom 2
224	90's Power Tom 3
225	90's Power Tom 4
226	90's Power Tom 5
227	90's Power Tom 6
228	Lo-Fi Tom 1
229	Lo-Fi Tom 1 Rim
230	Lo-Fi Tom 2
231	Lo-Fi Tom 2 Rim
232	Lo-Fi Tom 3
233	Lo-Fi Tom 3 Rim
234	Lo-Fi Tom 4
235	Lo-Fi Tom 4 Rim
236	Lo-Fi Tom 5
237	Lo-Fi Tom 5 Rim
238	Lo-Fi Tom 6
239	Lo-Fi Tom 6 Rim
240	Junkyard Tom 1
241	Junkyard Tom 1 Rim
242	Junkyard Tom 2
243	Junkyard Tom 2 Rim
244	Junkyard Tom 3
245	Junkyard Tom 3 Rim
246	Junkyard Tom 4
247	Junkyard Tom 4 Rim
248	Junkyard Tom 5
249	Junkyard Tom 5 Rim
250	Junkyard Tom 6
251	Junkyard Tom 6 Rim
252	Noise Tom 1
253	Noise Tom 1 Rim
254	Noise Tom 2
255	Noise Tom 2 Rim
256	Noise Tom 3
257	Noise Tom 3 Rim
258	Noise Tom 4
259	Noise Tom 4 Rim
260	Noise Tom 5
261	Noise Tom 5 Rim
262	Noise Tom 6
263	Noise Tom 6 Rim
264	Techno Tom 1

#	Voice	#	Voice	#	Voice
265	Techno Tom 1 Rim	303	Electronic Ride Edge	341	16" Standard Crash 1 Edge
266	Techno Tom 2	304	Electronic Ride Bell	342	16" Standard Crash 2
267	Techno Tom 2 Rim	305	20" Room Ride	343	16" Standard Crash 2 Edge
268	Techno Tom 3	306	20" Room Ride Edge	344	Brush Crash 1
269	Techno Tom 3 Rim	307	20" Room Ride Bell	345	Brush Crash 2
270	Techno Tom 4	308	HipHop Ride	346	Brush Crash 3
271	Techno Tom 4 Rim	309	20" Metal Ride	347	Brush Crash 4
272	Techno Tom 5	310	20" Metal Ride Edge	348	Funk Crash 1
273	Techno Tom 5 Rim	311	20" Metal Ride Bell	349	Funk Crash 1 Edge
274	Techno Tom 6	312	Old School Ride	350	Funk Crash 2
275	Techno Tom 6 Rim	313	Old School Ride Edge	351	Funk Crash 2 Edge
276	Magic Tom 1	314	Old School Ride Bell	352	19" Jazz Crash 1
277	Magic Tom 1 Rim	315	House Ride	353	19" Jazz Crash 1 Edge
278	Magic Tom 2	316	House Ride Edge	354	19" Jazz Crash 2
279	Magic Tom 2 Rim	317	House Ride Bell	355	19" Jazz Crash 2 Edge
280	Magic Tom 3	318	Vintage Ride	356	Rock Crash 1
281	Magic Tom 3 Rim	319	Vintage Ride Edge	357	Rock Crash 1 Edge
282	Magic Tom 4	320	Vintage Ride Bell	358	Rock Crash 2
283	Magic Tom 4 Rim	321	Lo-Fi Ride	359	Rock Crash 2 Edge
284	21" Acoustic Ride	322	Lo-Fi Ride Edge	360	808Crash
285	21" Acoustic Ride Edge	323	Lo-Fi Ride Bell	361	909Crash 1
286	21" Acoustic Ride Bell	324	Junkyard Ride	362	909Crash 2
287	22" Standard Ride	325	Junkyard Ride Edge	363	Electronic Crash 1
288	22" Standard Ride Edge	326	Junkyard Ride Bell	364	Electronic Crash 2
289	22" Standard Ride Bell	327	Noise Ride	365	Orchestra Crash 1
290	Brush Ride 1	328	Noise Ride Edge	366	Orchestra Crash 2
291	Brush Ride 2	329	Noise Ride Bell	367	Orchestra Crash 3
292	20" Funk Ride	330	22" Big Band Ride	368	Room Crash
293	20" Funk Ride Edge	331	22" Big Band Ride Edge	369	Room Crash Edge
294	20" Funk Ride Bell	332	22" Big Band Ride Bell	370	1970's Crash 1
295	22" Jazz Ride	333	Techno Ride	371	1970's Crash 2
296	22" Jazz Ride Edge	334	Techno Ride Edge	372	Old School Crash 1
297	22" Jazz Ride Bell	335	Techno Ride Bell	373	Old School Crash 1 Edge
298	20" Rock Ride	336	16" Acoustic Crash 1	374	Old School Crash 2
299	20" Rock Ride Edge	337	16" Acoustic Crash 1 Edge	375	Old School Crash 2 Edge
300	20" Rock Ride Bell	338	16" Acoustic Crash 2	376	Vintage Crash 1
301	808 Ride	339	16" Acoustic Crash 2 Edge	377	Vintage Crash 1 Edge
302	Electronic Ride	340	16" Standard Crash 1	378	Vintage Crash 2

#	Voice	#	Voice	#	Voice
379	Vintage Crash 2 Edge	420	14" Rock Hi-hat Edge 1	461	Low Bongo
380	Lo-Fi Crash 1	421	14" Rock Hi-hat Pedal 1	462	High Timbale 1
381	Lo-Fi Crash 1 Edge	422	14" Rock Hi-hat Splash 1	463	High Timbale 2
382	Lo-Fi Crash 2	423	14" Jazz Hi-hat	464	High Timbale 2 Rim
383	Lo-Fi Crash 2 Edge	424	14" Jazz Hi-hat Edge	465	High Timbale 3
384	Junkyard Crash 1	425	14" Jazz Hi-hat Pedal	466	High Timbale 3 Rim
385	Junkyard Crash 1 Edge	426	14" Jazz Hi-hat Splash	467	Low Timbale 1
386	Junkyard Crash 2	427	14" Rock Hi-hat 2	468	Low Timbale 2
387	Junkyard Crash 2 Edge	428	14" Rock Hi-hat Edge 2	469	Low Timbale 2 Rim
388	Noise Crash 1	429	14" Rock Hi-hat Pedal 2	470	Low Timbale 3
389	Noise Crash 1 Edge	430	14" Rock Hi-hat Splash 2	471	Low Timbale 4
390	Noise Crash 2	431	808 Hi-hat	472	High Agogo
391	Noise Crash 1 Edge	432	808 Hi-hat Pedal	473	Low Agogo
392	Big Band Crash 1	433	808 Hi-hat Splash	474	Claves
393	Big Band Crash 1 Edge	434	909 Hi-hat	475	Jingle Bell
394	Big Band Crash 2	435	909 Hi-hat Pedal	476	Cowbell
395	Big Band Crash 2 Edge	436	909 Hi-hat Splash	477	Bell Tree 1
396	Techno Crash 1	437	Dance Hi-hat	478	Bell Tree 2
397	Techno Crash 1 Edge	438	Dance Hi-hat Pedal	479	Tambourine
398	Techno Crash 2	439	Dance Hi-hat Splash	480	Cabasa
399	Techno Crash 2 Edge	440	Lo-Fi Hi-hat	481	Long Guiro
400	Latin Crash 1	441	Lo-Fi Hi-hat Edge	482	Short Guiro
401	Latin Crash 1 Edge	442	Lo-Fi Hi-hat Pedal	483	Indian 1
402	Latin Crash 2	443	Lo-Fi Hi-hat Splash	484	Indian 2
403	Latin Crash 2 Edge	444	Maracas	485	Indian 3
404	China 1	445	Metronome Bell	486	Indian 4
405	China 1 Edge	446	Vibra-slap 1	487	Indian 5
406	Splash	447	Vibra-slap 2	488	Indian 6
407	Splash Edge	448	Vibra-slap 3	489	Indian 7
408	14" Acoustic Hi-hat	449	Synthesis Percussion 1	490	Indian 8
409	14" Acoustic Hi-hat Edge	450	Synthesis Percussion 2	491	Indian 9
410	14" Acoustic Hi-hat Pedal	451	High Q 1	492	Indian 10
411	14" Acoustic Hi-hat Splash	452	High Q 2	493	Indian 11
412	14" Standard Hi-hat	453	Low Q 1	494	Indian 12
413	14" Standard Hi-hat Edge	454	Low Q 2	495	Indian 13
414	14" Standard Hi-hat Pedal	455	Mute Hi Conga 1	496	Indian 14
415	14" Standard Hi-hat Splash	456	Mute Hi Conga 2	497	Indian 15
416	Brush Hi-hat	457	Open Hi Conga 1	498	Indian 16
417	Brush Hi-hat Pedal	458	Open Hi Conga 2	499	Indian 17
418	Brush Hi-hat Splash	459	Low Conga	500	African 1
419	14" Rock Hi-hat 1	460	High Bongo	501	African 2

#	Voice
502	African 3
503	African 4
504	African 5
505	African 6
506	African 7
507	African 8
508	African 9
509	African 10
510	African 11
511	African 12
512	African 13
513	African 14
514	African 15
515	African 16
516	Marimba C3
517	Marimba G3
518	Marimba C4
519	Marimba Db4
520	Marimba D4
521	Marimba Eb4
522	Marimba E4
523	Marimba F4
524	Marimba Gb4
525	Marimba G4
526	Marimba Ab4
527	Marimba A4
528	Marimba Bb4
529	Marimba B4
530	Marimba C5
531	Marimba Db5
532	Marimba D5
533	Marimba Eb5
534	Marimba E5
535	Marimba F5
536	Marimba Gb5
537	Marimba G5
538	Marimba Ab5
539	Marimba A5
540	Marimba Bb5
541	Marimba B5
542	Marimba C6
543	Vibraphone C3
544	Vibraphone G3
545	Vibraphone C4

#	Voice
546	Vibraphone Db4
547	Vibraphone D4
548	Vibraphone Eb4
549	Vibraphone E4
550	Vibraphone F4
551	Vibraphone Gb4
552	Vibraphone G4
553	Vibraphone Ab4
554	Vibraphone A4
555	Vibraphone Bb4
556	Vibraphone B4
557	Vibraphone C5
558	Vibraphone Db5
559	Vibraphone D5
560	Vibraphone Eb5
561	Vibraphone E5
562	Vibraphone F5
563	Vibraphone Gb5
564	Vibraphone G5
565	Vibraphone Ab5
566	Vibraphone A5
567	Vibraphone Bb5
568	Vibraphone B5
569	Vibraphone C6
570	Orchestra Timpani C2
571	Orchestra Timpani Db2
572	Orchestra Timpani D2
573	Orchestra Timpani Eb2
574	Orchestra Timpani E2
575	Orchestra Timpani F2
576	Orchestra Timpani Gb2
577	Orchestra Timpani G2
578	Orchestra Timpani Ab2
579	Orchestra Timpani A2
580	Orchestra Timpani Bb2
581	Orchestra Timpani B2
582	Orchestra Timpani C3
583	Orchestra Timpani Db3
584	Orchestra Timpani D3
585	Orchestra Timpani Eb3
586	Orchestra Timpani E3
587	Orchestra Timpani F3
588	Orchestra Timpani Gb3
589	Orchestra Timpani G3

#	Voice
590	Orchestra Timpani Ab3
591	Orchestra Timpani A3
592	Orchestra Timpani Bb3
593	Orchestra Timpani B3
594	Orchestra Timpani C4
595	FX 1
596	FX 2
597	FX 3
598	FX 4
599	FX 5
600	FX 6
601	FX 7
602	FX 8
603	FX 9
604	FX 10
605	FX 11
606	FX 12
607	FX 13
608	FX 14
609	FX 15
610	FX 16
611	FX 17
612	FX 18
613	FX 19
614	FX 20
615	One
616	Two
617	Three
618	Four
619	Five
620	Six
621	Seven
622	Eight
623	Nine
624	Ti
625	Ta
626	Ei
627	An
628	E
629	Mute

Hi-Hat Combinations

Voice

630	Acoustic
631	FunkBand
632	Standard
633	Jazz
634	JazBrush
635	Rock
636	808
637	909
638	Dance
639	Marimba
640	Vibra
641	Indian
642	African
643	Lo-Fi