



## SamplePad Pro

Latest Firmware Version: 1.0.19

Release Date: August 17<sup>th</sup>, 2015

### Firmware Update Instructions

1. Add the **LDSP\_UPD.DAT** and **LDSP2UPD.DAT** files (located in this **.zip** file) to the root folder level of a standard SD card (where you would normally place WAV files when using them with SamplePad Pro).
2. Insert the SD card into SamplePad Pro's **SD Card Slot**.
3. On SamplePad Pro, hold down the **Cursor Up** and **Cursor Left** buttons, and press the **Power Switch** to power it on.
4. When **Press any key to update...** appears in the **LCD** screen, press any one of SamplePad Pro's **Cursor Buttons**.
5. When **Update Success! Restart...** appears in the **LCD**, press the **Power Switch** to power it off, and then press it again to power it back on. Confirm that the new firmware version **LDSP V1.0.19 2015-8-13** appears in the LCD.  
Congratulations! Your SamplePad Pro now has the newest firmware!

### **Changes in v1.0.19**

- Minor bug fixes.

### **Changes in v1.0.15**

- Updated **SENS** parameter default value to **2**.
- Other minor bug fixes.

### **Changes in v1.0.14**

- Refined **SENS** parameter to add control of the threshold for each internal pad or external input. The threshold sets the amount of force needed to trigger the pad. The lower that the **SENS** parameter is set, the more force will be required to trigger the pad.
- Other minor bug fixes.

### **Changes in v1.0.10**

- Improved pad sensitivity while playing multiple pads at the same time.

### **Changes in v1.0.9**

- Fixed an issue with using WAV files exported from Avid® Pro Tools® and Steinberg Cubase™.
- Fixed an issue with playing multiple samples set to Loop mode in the same mute group.

### **Technical Support**

For additional help, visit [alesis.com/support](https://alesis.com/support).